



# Taber 1000/8000 IOM

## TABER 1000/8000 SERIES STANDARD CONFIGURATION ALL -10 MODELS




# Taber 1000/8000 IOM

## TABER 1000/8000 SERIES STANDARD CONFIGURATION ALL 20 MODELS




**Taber 1000/8000 IOM**

**TABER 1000/8000 SERIES STANDARD CONFIGURATION  
ALL -30 MODELS**



# Taber 1000/8000 IOM

## TABER 1000/8000 SERIES STANDARD CONFIGURATION ALL -40 MODELS



# Taber 1000/8000 IOM

## TABER 1000/8000 SERIES STANDARD THRUST BEARING ALL -10 & -20 MODELS

